Wiring Diagram and Programming Instructions for MAW6 Digital Keypad and Proximity Card/F reader

Grant's Automation

Developers and Manufacturers of Gate Automation Technology

www.grantsautomation.com.au - grant@grantsautomation.com.au

Wiring Diagrams for MAW6 Digital Keypad

For Pedestrian Gates fitted with an electric Strike Lock or magnetic Lock



Exit Button will activate the Devices output timer in the same manner that entering a correct code or touching a programmed tag or card does. Ideal as a way for pedestrians to exit without a code.

'Door In' is for a magnetic reed or micro switch fitted to a gate to activate an alarm if not closed in 1 minute after use.

For 12V Automatic Gate Operator or 240V Operator with 12VDC output for accessories.



Wiring Diagrams for MAW6 Digital Keypad

For 24V Automatic Gate Operator or 240V operator with 24VAC or DC output for accessories.



For Access Control/Alarms system



Programming Instructions for MAW6 Digital Keypad and Card reader

FEATURES:

- Up to 2000 User Codes (4 Digits), touch tags or cards all with a seperate user ID number so they can be removed even if tag or card is lost or code is forgotten. Note: need to keep a log book
- Can use Code or Tag/Card or Code + Tag/Card for extra security
- Activation time from 0 to 99 seconds.
- Users can change their own Code or Card without Master Code
- Keypads give a visual as well as acoustic signaling while entering codes

PROGRAMMING:

To Add a User Code or Tag/Card by ID



To Add many Tags/ Cards



To Remove a User Code or Tag/Card by ID



Grant's Automation | Developers and Manufacturers of Gate Automation Technology

www.grantsautomation.com.au - grant@grantsautomation.com.au

PROGRAMMING:

To Remove a Tag/Card with Tag/Card



To Remove all User Codes or Tags/Cards



Set Tag/Card only Option



Set Tag/Card & Code Option



Set Tag/Card OR Code Option (default)



To Change Activation Time



Grant's Automation | Developers and Manufacturers of Gate Automation Technology

www.grantsautomation.com.au - grant@grantsautomation.com.au

Programming Instructions for MAW6 Digital Keypad

To Change a User Code



To Change the Master Code



Restoring Factory Settings.

The factory settings can be recovered it necessary without loosing any user codes, tags or cards programmed in. To do this remove power from the device, then after 15 seconds press and hold the "#' key and restore power. When the decive beeps left go of the "#" key as the factory settings have been restored.

Record Master Code Here:

Record User ID numbers and Codes Here:		
User Name and/or Description	User ID Number	User Code

Grant's Automation | Developers and Manufacturers of Gate Automation Technology

www.grantsautomation.com.au - grant@grantsautomation.com.au